



# **WIRELESS AUDIO ADAPTER**

TRANSMITTER & RECEIVER | 2-IN-1













# **HOW TO USE** ▼

# **FIRST TIME PAIRING** & RECONNECTING



### SELECT DIRECTION

Use the Pairing switch to select the audio direction in or out.



### POWER ON AND CONNECT

Press and hold the Control button for 3 (IN) or 5 (OUT) seconds to power on and connect or automatically reconnect to the last device.



# **POWER OFF**

Press and hold the Control button for 3 seconds.

The adapter will automatically reconnect to the last connected device when powered on. To reset the adapter, press and hold the Control button for 6 seconds from power on.

## **PAIRING SWITCH MODE**



# **RECEIVE AUDIO**

For auto, speakers etc.







SPEAKER

TRANSMIT AUDIO (OUT Connect to any Bluetooth-enabled devices on airplanes, TV, etc.



INFLIGHT





# WORKS WITH ▼

## **SUITABLE FOR**





Wireless Headphones

Wireless Earphones

Bluetooth® 5.0 and above .....

## **COMPATIBILITY**











Inflight

Auto

Gym Machines

Gaming

Computers

